

Throstle Nest Mill, Leeds Road, Nelson, Lancashire, England BB9 7QZ. Phone - 01282 696214. Fax - 01282 697319 www.daledoc.co.uk - www.jaysracewear.co.uk salesoffice@dale-techniche.co.uk

Care & Usage Sheet

Issue 6 Date: 04.05.2021



PROTECTIVE APRON PG2A, PG2/AA, PG2/F & PG2/FF LEATHER FRONT

TECHNICAL:

This garment has been designed to give a specified level of protection against accidental contact with blades and similar sharp implements. In the design of this garment due respect has been paid to the basic health and safety requirements laid out in PPE Regulation 2016/425 as brought into UK Law and amended. The garment has been tested in accordance with EN 388: 2016.

Tested in accordance		Level	Minimum	Maximum
with			level	level
EN388:2016	Abrasion resistance	4	0	4
	Blade cut resistance	Х	0	5
	Tear resistance	4	0	4
	Puncture resistance	4	0	4
	TDM Cut resistance	F	А	F
4X44F				



X = Not tested

Sizes – PG2/A & PG2/AA one size only, depth 500mm or bib style one size only. PG2/F & PG2/FF one size only depth adjustable to 500, 600 of 700mm.

WARNING: The garment is <u>CUT RESISTANT</u> not CUT PROOF. The actual conditions of use cannot be simulated and it is the responsibility of the user, not the manufacturer, to determine the garment's suitability for the intended use. The garment is sold without warranty expressed or implied. No warranty or representation is made as to the product's ability to protect the user from injury or death. The user assumes that responsibility. Do not use next to moving machinery.

USE:

New and used garments should be thoroughly inspected before use to ensure no damage is present. Should any areas of high visibility orange colour be seen when the garment is viewed from the front, leather side, then the protective inner fabric has been compromised. Such a garment should be replaced immediately.

Tie straps are designed to be passed completely round the waist and fastened at the front. The straps can be threaded through the upper middle or lower eyelet holes to adjust the length of the apron according to the wearer's height and the area of protection required. Tie securely around the waist, ensure that the apron does not slip easily from side to side,

GARMENT CARE:

Stored garments should be kept in a dry place away from heat and direct sunlight. Clean using a damp sponge when required. This garment can be disposed of/recycled in the same way as normal textile fabrics/garments.

REPAIR: Do not repair this garment.

Notified Body:

EU type examination performed by SATRA Technology Europe, Bracetown Business Park, Clonee, D15 YN2P Ireland. Notified Body number 2777.

<u>Approved body for Type Approval:</u> SATRA Technology Centre Ltd (AB 0321), Wyndham Way, Telford Way, Kettering, Northamptonshire, NN16 8SD, UK.

Further information on this garment can be obtained from Dale Techniche Ltd. at the location shown at the top of this page. EU certificates of conformity can be accessed by logging on to <u>www.daledoc.co.uk</u>